

Son 1	Son 2	Switch	Genre du son	Fréquence du son	Fréquence de cycles	12VDC		EN54-3* 15VDC	24VDC		EN54-3* 28VDC
						mA	dB(A)		mA	dB(A)	
1	14	11111	Son alterné	800/970Hz	2Hz (250ms-250ms)	6	95		13	101	
2	14	11110	Son croissant	800-970Hz	7Hz (7/s)	8	94		12	100	
3	14	11101	Son croissant	800-970Hz	1Hz (1/s)	20	95	92	40	102	95
4	14	11100	Son continu	2850Hz		16	99		32	105	
5	4	11011	Son croissant	2400-2850Hz	7Hz	16	103		32	109	
6	4	11010	Son croissant	2400-2850Hz	1Hz	16	105		32	112	
7	14	11001	Appel lent	300-1200Hz	3s/0.5s Pause	6	97	93	12	103	97
8	14	11000	Son décroissant	1200-500Hz	1Hz	7	96	93	15	103	94
9	4	10111	Son alterné	2400/2850Hz	2Hz (250ms-250ms)	15	99		31	105	
10	14	10110	Son intermittent	970Hz	0.5Hz (1s On/1s Off)	5	95		8	101	
11	14	10101	Son alterné	800/970Hz	1Hz (500ms-500ms)	6	95		12	101	
12	4	10100	Son intermittent	2850Hz	0.5Hz (1s On/1s Off)	9	99		17	105	
13	14	10011	Son intermittent	970Hz	0.8Hz (250ms On/1s Off)	3	94		5	101	
14	14	10010	Son continu	970Hz		7	95	93	14	101	96
15	14	10001	Son alterné	554/440Hz	100ms-400ms	8	96		17	102	
16	16	10000	Son intermittent	660Hz	3.3Hz (150ms On/150ms Off)	4	94		6	100	
17	17	01111	Son intermittent	660Hz	0.28Hz (1.8s On/1.8s Off)	4	95		7	101	
18	18	01110	Son intermittent	660Hz	0.05Hz (6.5Hz On/13s Off)	3	95		6	101	
19	19	01101	Son continu	660Hz		5	95		10	101	
20	20	01100	Son alterné	554/440Hz	0.5Hz (1s On/1s Off)	7	96		16	102	
21	21	01011	Son intermittent	660Hz	1Hz (500ms-500ms)	4	94		6	101	
22	14	01010	Son intermittent	2850Hz	4Hz (150ms On/100ms Off)	12	98		27	104	
23	14	01001	Son croissant	800-970Hz	50Hz	6	93		12	100	
24	4	01000	Son croissant	2400-2850Hz	50Hz	15	102		32	108	
25	25	00111	Son intermittent	970Hz	3x500ms/1.5s Pause	4	95		7	101	
26	26	00110	Son intermittent	800-970Hz	3x500ms/1.5s Pause	4	95		6	102	
27	27	00101	Son intermittent	970/800Hz	3x500ms/1.5s Pause	3	94		6	101	
28	10	00100	Son alterné	800/970Hz	2Hz (250ms-250ms)	6	95		12	101	
29	33	00011	Son alterné	990/650Hz	2Hz (250ms-250ms)	10	99	93	20	105	96
30	35	00010	Son alterné	510/610Hz	2Hz (250ms-250ms)	8	94	91	16	100	92
31	31	00001	Son croissant	300-1200Hz	1Hz	10	98		22	103	
32	32	00000	Son alterné	510/610Hz	1Hz (500ms-500ms)	8	95		16	100	

\*EN54-3: Gamme de tension 9-15VDC et 18-28VDC